

3200 NXT Timer Diagnostic Mode Flow Chart

Model

<i>Control Valve S/N:</i>				
<i>Current Flow Rate:</i>				
<i>Peak Flow Rate:</i>				
<i>Totalizer:</i>				
<i>Last Two Regens:</i>				
<i>Last Regen:</i>				
<i>Volume Remaining Tank:</i>				
<i>Volume Remaining System:</i>				
<i>Valve Address:</i>				
<i>Software Version:</i>				

Entering Diagnostic Mode:

1. Push and release the “D” Button.
2. Press the Extra Cycle button once per display until all displays are viewed and Normal Display is resumed.
3. Push and release the “D” button at anytime during diagnostic mode and the timer will exit the mode.
4. Depending on current valve programming, certain displays may not be able to be viewed or set.

Resets:

Soft Reset: Press and hold the Up and Down buttons for 25 seconds until 12:00PM (or 12:00HR) appears. This resets all parameters except for the flow meter totalizer volume.

Master Reset: Hold the Extra Cycle button while powering up the unit. This resets all of the parameters in the unit. Check and verify the choices selected in Master Programming Mode.

Additional notes: